

FRS KIT AND BRACKET KIT SELECTION GUIDE

Note:

- KERDI-SHOWER-FRS Kits and Bracket kits were developed to accommodate standard installation conditions and common outliers. Additional brackets may be required in certain installations.

Sqft	12 sqft kit	16 sqft kit	J-Bracket kit	P-Bracket kit
0-12	1	0	0	0
13-15	1	0	1	1
16	0	1	0	0
17-18	0	1	0	1
19-20	0	1	1	1
21	0	1	4	1
22-27	2	0	0	0
28-31	2	0	1	0
32-35	2	0	2	0
36-40	2	0	3	0

If you have a 5/8" subfloor continue to the shim selection guide below

SHIM SELECTION GUIDE

Item No.	SHIMS needed (2 per P-bracket)
KS FRS K16	54
KS FRS K12	42
KS FRS KP4	8
KS FRS KJ2	0

Note:

- Each shim kit contains 60 shims.
Item number: KS FRS SH60