

Installation instructions

Schlüter®-DESIGN-NICHE





If the studwork is installed but no plasterboard fitted



Create a studwork frame for the niche body to sit in:

- **Niche A:** Stud frame should measure 320 x 305 mm
- **Niche B:** Stud frame should measure 320 x 605 mm
- **Niche C:** Stud frame should measure 320 x 1205 mm



Place the niche frame on to a piece of plasterboard and cut around the outside of the frame.



Fix the plasterboard with the hole cut in it (step 2) to the studwork so the hole and studwork frame align



Using the supplied tube of KERDI-FIX, glue the spacers to the studwork frame.



Using the piece of plasterboard cut out in step 2 and the wall tile that will be used (plus a small piece of DITRA-PS to mimic a bed of tile adhesive) as a guide, use the adjustable nuts on the niche body to slide it backwards or forwards until it is set to the required depth - either flush with the surface of the tiled wall or protruding out from the tiled wall - and tighten the nuts



Apply KERDI-FIX to the surface of the spacers.



Slot the niche into the opening, gently pushing the frame on to the KERDI-FIX on the surface of the spacers



Use KERDI-FIX to completely fill the joint between the niche body and the niche frame.



Using KERDI-COLL-L-185 adhere the KERDI-collar to the niche frame and surrounding plasterboard, creating a waterproof seal

Learn more online

Would you like to know more about Schlüter-Systems?
The quickest way is to visit our website.

schluter.co.uk



You can also follow us on Instagram, Facebook and YouTube.



Schlüter-Systems KG  Schmölestraße 7 | D-58640 Iserlohn

 +49 2371 971-0  +49 2371 971-1111  info@schluter.de  schluter-systems.com

Schlüter-Systems Ltd  Units 3-6 Bardon 22 Industrial Estate | Bardon Hill | Coalville | Leicestershire | LE67 1TE

 +44 (0) 1530 813396  sales@schluter.co.uk  schluter.co.uk